

Multiwall Installation Instructions

Safety Recommendations

- Never walk on or apply your weight directly to sheeting. Use walking boards along rafters at all times.
- Always exercise extreme care when walking on a roof and consider all safety requirements when working at heights.
- For safety precautions we recommend the use of safety mesh for installations above 3m.
- Use personal protective equipment such as safety footwear, safety glasses and gloves.
- We do not recommend the collection of drinking water from any roof without appropriate precautions and filtration (check with your local water authority for further advice).
- All installations and safety practices must comply with the applicable building and/or work cover codes.

Table 1.

Rafter Nominal Spacing (mm)

Sheet Thickness	Sheet Width	Rafter Spacing
10mm	700mm	720mm
10mm	1050mm	1070mm

- 1 Install sheets with the ribs (flutes) running vertically in the direction of the fall on the roof with a minimum pitch of 5 degrees. Having sufficient fall allows natural weather action to assist in keeping the sheets clean and minimises leaking.
- 2 Check recommendation for rafter spacing in Table 1.
- Multiwall sheets can be cut using a sharp knife, hand saw or circular saw with a fine tooth blade suitable for plastics. Sawdust (swarf) should be cleared from the channels with compressed air (or vacuumed) and edges should be free of notches.

If the width of the Multiwall sheets needs to be reduced, trim them as close as possible to the last rib so that optimum clamping action of the glazing bar is ensured.

- Peel some of the masking back from the ends of the sheet and apply Breather Tape to the top and Sealing Tape to the bottom ends
- 5 Place the first measured and cut Edge Bar down squarely on the structure (screw side up).




One Piece H-Bar System
Place the first measured and
cut H-Bar down squarely on the

cut H-Bar down squarely on the structure (screw side up).



Two Piece H-bar System
Place the first measured and
cut base glazing bar on the
structure.



The maximum end overhang is 50mm.

One Piece H-Bar System
Secure the H-Bar to the rafter
with a screw (gauge not
exceeding 12g) at no greater
than 1200mm apart.


Two Piece H-bar System

Fasten the Base Glazing Bars to the rafter with Ripple Tek screws (10 gauge – 16 tpi) at no greater than 500mm apart by fixing through the center of the base glazing bar and securing it firmly onto the supporting structure. (Ripple Teks for Wood are 30mm long; Ripple Teks for Metal are 21mm in length)

Pull the masking back on the sides of the sheet and place the H-Bar gasket along the whole length of both sides of the sheet.



One Piece H-Bar System
Place the next H-Bar on the
other side and secure it to the
support structure.




Two Piece H-bar System
Place the sheet between the secured glazing bars. Position the first top glazing bar in line with the base. Secure the two



It is recommended that the top glazing bar is secured to the rafter with screws (gauge not exceeding 12g) at no greater than 1200mm apart. Once the next sheet is installed the second and subsequent top glazing bars can be fitted.

- 9 Repeat steps 6-8 until all sheets are in position.
- When using Aluminium End Caps, place the end gasket along the end of the Multiwall sheet only, stopping at the H-Bar.



Fasten the Aluminium End Cap with a screw to the H-Bar. On the underneath of the Aluminium End Cap drill a small weep hole where it meets the H-Bar.



12 Use the Edge Bar to finish the assembly on the final rafter.

IMPORTANT